



## LOAD SENSING PROPORTIONING AND BY-PASS VALVE (LSP & BV) COMPONENTS




### CHECK AND ADJUSTMENT OF FLUID PRESSURE

#### 1. SET REAR AXLE LOAD


Rear axle load (includes vehicle weight):

2WD	700 kg (1,543 lb)
4WD	750 kg (1,653 lb)



#### 2. INSTALL LSPV GAUGE (SST) AND BLEED AIR SST 09709-29017

**B02030**




3. **RAISE FRONT BRAKE PRESSURE TO 50 kg/cm<sup>2</sup> (711 psi, 4,903 kPa) AND CHECK REAR BRAKE PRESSURE**

Rear brake pressure:

2WD 37 ± 5 kg/cm<sup>2</sup> (526 ± 71 psi, 3,628 ± 490 kPa)  
 4WD 36 ± 5 kg/cm<sup>2</sup> (512 ± 71 psi, 3,530 ± 490 kPa)

NOTE: The brake pedal should not be depressed twice and/or returned while setting to the specified pressure. Read the value of rear brake pressure two seconds after adjusting the specified fluid pressure.




4. **RAISE FRONT BRAKE PRESSURE TO 100 kg/cm<sup>2</sup> (1,422 psi, 9,807 kPa) AND CHECK REAR BRAKE PRESSURE**

Rear brake pressure:

2WD 56 ± 7 kg/cm<sup>2</sup> (796 ± 100 psi, 5,492 ± 686 kPa)  
 4WD 55 ± 7 kg/cm<sup>2</sup> (782 ± 100 psi, 5,394 ± 686 kPa)

If the brake pressure is incorrect, adjust the fluid pressure.



5. **IF NECESSARY, ADJUST FLUID PRESSURE**

(a) Adjust the length of the No.2 shackle.

Low pressure — Lengthen A  
 High pressure — Shorten A


Initial set:

2WD 78mm (3.07 in.)  
 4WD 120mm (4.72 in.)

Adjusting range:

2WD 72 — 84 mm (2.83 — 3.31 in.)  
 4WD 114 — 126 mm (4.49 — 4.96 in.)

NOTE: One turn of the No.2 shackle changes the fluid pressure about 0.6 kg/cm<sup>2</sup> (8.5 psi, 59 kPa).



(b) In event the pressure cannot be adjusted by the No.2 shackle, raise or lower the valve body.


Low pressure — Lower  
 High pressure — Raise

(c) Torque the nuts.

Torque: 130 kg-cm (9 ft-lb, 13 N·m)

(d) Adjust the length of the No.2 shackle again.

If it cannot be adjusted, inspect the valve housing.




## 6. IF NECESSARY, CHECK VALVE BODY

(a) Assemble the valve body in the uppermost position

NOTE: When the brakes are applied, the piston will move down about 1 mm (0.04 in.). Even at this time, the piston should not make contact with or move the load sensing spring.

(b) In this position, check the rear brake pressure.



kg/cm<sup>2</sup> (psi, kPa)


Front brake pressure	Rear brake pressure
5 (71, 490)	5 (71, 490)
50 (711, 4,903)	19.7–23.7 (280–337, 1,932–2,324)
80 (1,138, 7,845)	29.8–35.8 (424–509, 2,922–3,511)

If the measured value is not within standard, replace the valve body.

## REMOVAL OF LSP & BV OR LSPV

(See page BR-50)

### 1. DISCONNECT SHACKLE NO.2 FROM BRACKET




### 2. REMOVE LSP & BV (LSPV) ASSEMBLY

(a) Using SST, disconnect the brake tube from the valve body.

SST 09751-36011


(b) Remove the valve bracket mounting bolts and remove the LSP & BV (LSPV) assembly.




## INSPECTION OF LSP & BV OR LSPV

### INSPECT VALVE PISTON PIN AND LOAD SENSING CONTACT SURFACE FOR WEAR

Wear limit: 0.7 mm (0.028 in.)







**INSTALLATION OF LSP & BV OR LSPV**

(See page BR-50)

**1. ASSEMBLE FOLLOWING PARTS TO LOAD SENSING SPRING:**

- (a) Load sensing valve boot
- (b) Load sensing spring boot
- (c) Bushings
- (d) Rubber plates
- (e) Bushings
- (f) Collars


**NOTE:** Apply rubber grease to all rubbing areas. Do not mistake the valve side for the shackle side of the load sensing spring.




**2. ASSEMBLE VALVE BODY TO BRACKET**

Assemble the valve body to the valve body bracket.

**NOTE:** Finger tighten the valve body mounting nuts.



**3. CONNECT VALVE BODY AND NO.1 SHACKLE TO LOAD SENSING SPRING**



**4. INSTALL LSP & BV (LSPV) ASSEMBLY TO FRAME**

**Torque:** 195 kg-cm (14 ft-lb, 19 N·m)


**5. CONNECT BRAKE TUBE**

Using SST, connect the brake tubes.

Torque the nut.


**Torque:** 155 kg-cm (11 ft-lb, 15 N·m)

SST 09751-36011



#### 6. CONNECT SHACKLE NO.2 TO BRACKET

- (a) Install shackle No. 1 and shackle No.2 to the load sensing spring.
- (b) Set dimension A by turning shackle No.2.  
Initial set:    2WD 78 mm (3.07 in.)  
                  4WD 120 mm (4.72 in.)
- (c) Connect shackle No. 2 to the shackle bracket.



#### 7. SET REAR AXLE LOAD (See page BR-50)

#### 8. SET VALVE BODY

- (a) When pulling down the load sensing spring, confirm that the valve piston moves down smoothly.
- (b) Position the valve body so that the valve piston lightly contacts load sensing spring.
- (c) Tighten the valve body mounting nuts.

#### 9. BLEED BRAKE LINE (See page BR-6)

#### 10. CHECK AND ADJUST LSP & BV FLUID PRESSURE (See page BR-50)

